

# IR319B Single and IR320B Dual Patient Stations

**IL713 Specification Sheet** 

Tek-CARE®300II Nurse Call System • Rev. 5 - 11/2016

#### **Features**

- UL<sup>®</sup> 1069 Listed
- Supervised
- All stations interchangeable
- Simplified multiplex wiring and plug-in connectors
- Input available for Hill-Rom® Sidecom® beds or remote call-in button applications
- Uses pillow speakers or push-button call cords



The IR319B Single Patient Station provides reliable twoway, hands-free communication between patient and nurse, and provides for programmable privacy, paging and patient priority from the master station. Calling the nurse is accomplished by pressing the call cord button or the area indicated nurse on the pillow speaker. Solid state LEDs on the panel indicate the call has been placed and the intercom is in use.

If the pillow speaker or call cord is accidentally removed from its receptacle, the nurse master station registers a non-cancellable cord out call. The call may be reset only by returning the call cord or pillow speaker to its receptacle.

The IR320B Dual Patient Station has the same specifications and functions as the IR319B, plus an additional independently operating call cord/pillow speaker receptacle and a second call-placed indicator.

## Listings



UL® 1069 listed; UL® File Number E71599.





IR319B Single and IR320B Dual Patient Stations

#### **Specifications**

Dimensions: Height: 4.5" (114 mm)

 Width:
 6.375"
 (162 mm)

 Depth:
 2.75"
 (70 mm)

 Projects:
 1.0"
 (25 mm)

above mounting surface

Construction: Flame-retardant (UL® 94V-0) plastic

faceplate

Speaker:  $2.5" \times 2.5" (64 \text{ mm} \times 64 \text{ mm})$ 

Connections: Plug-in type

Housing: Steel City #H3BD and #3GC plaster ring,

or exact equal. Horizontal mount.

## **Required Components**

Tek-CARE®300II Nurse Call System